

# CT STRAIGHTS

## 1/2" SHANK STRAIGHT BITS



PART# 1084




Part Number	Cutting Diameter	Cutting Length	Overall Length	Special Use
<b>1/2" SHANK • SINGLE FLUTE</b>				
1049	3/8"	1"	2 5/8"	
1050	3/8"	1 1/4"	2 7/8"	
1051	1/2"	3/4"	2 3/8"	Midwest Machine
1052	1/2"	1 1/4"	2 7/8"	
1054	1/2"	1 1/2"	3 1/8"	
1055	1/2"	2"	4 1/8"	
1055A	1/2"	2 1/2"	4 3/8"	
<b>1/2" SHANK • DOUBLE FLUTE</b>				
1058	1/4"	3/4"	2 3/8"	Incra™
1059	9/32"	3/4"	2 3/8"	
1060	5/16"	1"	2 5/8"	
1061	3/8"	3/4"	2 3/8"	
1062	3/8"	1"	2 5/8"	Incra™
1063	3/8"	1 1/4"	2 7/8"	
1064	13/32"	3/4"	2 1/2"	
1065	7/16"	1 1/4"	2 7/8"	
1065L	7/16"	1 1/4"	3 1/4"	Leigh #150
1065A	31/64"	1"	2 5/8"	Undersize Plywood Dado
1066	1/2"	1"	2 5/8"	
1067	1/2"	1 1/4"	2 7/8"	Leigh #160
1067F	1/2"	1 1/4"	2 7/8"	Carbide Boring Point
1069	1/2"	1 1/2"	3 1/8"	
1069DS	1/2"	1 1/2"	3 1/8"	Down Shear
1070	1/2"	1 1/2"	4 1/8"	
1071	1/2"	2"	3 1/2"	
1072	1/2"	2"	4 1/8"	
1073	1/2"	2 1/2"	4 3/8"	
1074	17/32"	1 1/4"	2 7/8"	
1075	9/16"	1 1/4"	3"	
1075A	19/32"	3/4"	2 1/4"	Undersize Plywood Dado
1076	5/8"	1"	2 1/2"	
1076F	5/8"	1"	2 1/2"	Carbide Boring Point
1077	5/8"	1 1/4"	3"	
1078	5/8"	1 1/2"	3"	
1079	5/8"	2"	4"	
1080	21/32"	1 1/4"	3"	
1082	11/16"	1"	2 1/2"	
1083	11/16"	1 1/4"	3"	
1083A	23/32"	1"	2 1/2"	Undersize Plywood Dado
1302A	3/4"	5/8"	2 1/4"	Mortising
1084	3/4"	1"	2 3/4"	
1085	3/4"	1 1/4"	3"	
1085F	3/4"	1 1/4"	3"	Carbide Boring Point
1086	3/4"	1 1/2"	3 1/4"	
1087	3/4"	2"	3 5/8"	
1088	25/32"	1 1/4"	3"	
1090	13/16"	1 1/4"	3"	
1091	7/8"	1 1/4"	3"	
1093	1"	1 1/4"	3"	
1093F	1"	1 1/4"	3"	Carbide Boring Point
1094	1"	1 1/2"	3"	
1095	1"	2"	3 3/4"	
1096	1 1/8"	1 1/2"	3"	
1304	1 1/4"	1/2"	2 1/8"	Mortising
1097	1 1/4"	1 1/2"	3"	
1098	1 3/8"	1 1/4"	3"	
1099	1 1/2"	1 1/4"	3"	
1100	1 3/4"	1 1/4"	3"	
1101	2"	1 1/4"	3"	

## STRAIGHT CUT CABINET DADO BITS For Undersized Plywood




PART# 1024A



Part Number	Cutting Diameter	Plywood Size	Cutting Length	Overall Length
<b>1/4" SHANK • DOUBLE FLUTE</b>				
<sup>sc</sup> SC13	7/32"	1/4"/5.5mm	3/4"	2"
1024A	31/64"	1/2"	3/4"	2 1/4"
1027A	19/32"	5/8"	3/4"	2 1/4"
1029A	23/32"	3/4"	3/4"	2 1/8"
<b>1/2" SHANK • DOUBLE FLUTE</b>				
1065A	31/64"	1/2"	1"	2 5/8"
1075A	19/32"	5/8"	3/4"	2 1/4"
1083A	23/32"	3/4"	1"	2 1/2"

<sup>sc</sup> - Solid Carbide

## TEMPLATE BITS Ball Bearing Guide



PART#3012



Part Number	Cutting Diameter	Cutting Length	Overall Length	Bearing Number
<b>1/4" SHANK</b>				
* 3000A	1/2"	1/8"	1 3/4"	B9
* 3000	1/2"	1/4"	1 7/8"	B9
3002	1/2"	3/4"	2 1/4"	B9
3004	1/2"	1"	2 1/2"	B9
* 3006	5/8"	1/4"	1 3/4"	B6
K41	5/8"	1/2"	2 1/4"	B6
K43	5/8"	3/4"	2 1/2"	B6
3008	5/8"	1"	2 1/2"	B6
* 3010	3/4"	1/4"	1 3/4"	B4
3012	3/4"	3/4"	2 3/8"	B4
3014	3/4"	1"	2 5/8"	B4
<b>3/8" SHANK</b>				
3015	7/8"	1"	2 5/8"	B12
<b>1/2" SHANK</b>				
3016	1 1/8"	1"	3"	B11
3018	1 1/8"	1 1/2"	3 1/2"	B11
3019	1 1/8"	2"	4"	B11
*** 3020	3/4"	1"	2 3/4"	B19
*** 3021	3/4"	1 1/4"	3"	B19
*** 3022	3/4"	1 1/2"	3 1/4"	B19
*** 3023	3/4"	2"	3 5/8"	B19

\* Dado Clean out bits. Use to Square the bottom of dado cuts made on a table saw.

\*\*\* Whiteside recommends the 1 1/8" dia tools in the 1/2" shank whenever possible due to the fragile nature of the B19 bear-